#### Mix Design

### OBJECTIVES OF MIX DESIGN

- EVALUATE MATERIALS
- DETERMINE AGGREGATE PROPORTIONS
- DETERMINE OPTIMUM ASPHALT CONTENT
- EVALUATE DESIGN MIX

#### **AGGREGATE EVALUATION**

- GRADATION
- L A ABRASION
- FRACTURED FACES
- NATURAL SAND
- FLAT AND ELONGATED



#### Aggregate Sample Splitter











#### **Types of Sampling**

- Representative
- Random

#### **Gradation / Sieve Analysis**

• ASTM D5444





#### Los Angeles Abrasion

- ASTM C535 & ASTM C131
- Aggregate is placed in a steel drum with 12 steel balls for the required number of revolutions.
- Percent loss is then calculated as the LA abrasion.

#### **Fractured Faces**


• ASTM D5821







#### Flat & Elongated










#### **BINDER PROPERTIES**

- VISCOSITY GRADED
- PG GRADED

#### **VISCOSITY GRADED**

- VISCOSITY
- VISCOSITY AFTER TFOT
- DUCTILITY


# Types of Wiscosity Tulbes



Courtesy of NCAT

#### **PG GRADED**

- DYNAMIC SHEAR RHEOMETER
- BENDING BEAM RHEOMETER
- ROTATIONAL VISCOMETER





#### **Dynamic Shear Rheometer**







#### **Direct Tension Tester**









#### **Bending Beam Rheometer**



## BINDER TESTS NOT NORMALLY CONDUCTED IN FIELD LAB

## IF AGGREGATE PROPERTIES AND ASPHALT PROPERTIES ARE OK THEN DETERMINE OPTIMUM ASPHALT CONTENT

## TWO METHODS GENERALLY USED TO DETERMINE OPTIMUM ASPHALT CONTENT

- MARSHALL
- SUPERPAVE

#### MARSHALL METHOD

- DEVELOPED BY CORPS OF ENGINEERS
- SIMPLE, QUICK, INEXPENSIVE

## What is Superpave?

## Superpave is a Mix Design Procedure and a Binder Classification System


#### SUPERPAVE METHOD

- DEVELOPED IN 1990's
- NOT YET ADOPTED FOR AIRFIELDS
- INVOLVES USING NEWLY DEVELOPED GYRATORY COMPACTOR



## USES 6-INCH DIAMETER SAMPLES





#### MARSHALL METHOD

- DEVELOPED BY CORPS OF ENGINEERS
- SIMPLE, QUICK, INEXPENSIVE

## USES 4-INCH DIAMETER SAMPLES

## BLEND 15 TO 20 AGGREGATE SAMPLES AT SELECTED PROPORTIONS

### VARY ASPHALT CONTENT IN 0.5 % INCREMENTS



### COMPACT SAMPLES USING SPECIFIED EFFORT


#### THREE TYPES OF HAMMER

- MANUAL
- MECHANICAL
- MECHANICAL WITH SLANTED FOOT AND ROTATING BASE

## Pedestal and Hammer Requirements

- Pedestal should be on solid base
- Use manual hammer
- Make sure hammer is proper weight and no significant friction
- Make sure pedestal is not cracked










### **Bulk Specific Gravity**





### **CoreLok Specific Gravity**































## TYPICALLY SELECT OPTIMUM ASPHALT CONTENT AT 4 PERCENT AIR VOIDS





# AFTER SELECTING OPTIMUM ASPHALT CONTENT CHECK FOR STABILITY AND MOISTURE SUSCEPTIBILITY



### **Marshall Stability**






Determine the tensile strengths of both sets of 3 specimens

Calculate the Tensile Strength Ratio (TSR) Avg. wet tensile strength


Avg. dry tensile strength

TSR =

Minimum of 80% needed








### **Asphalt Pavement Analyzer**





# THE MIX DESIGN IS A STARTING POINT AND WILL LIKELY HAVE TO BE ADJUSTED DURING PRODUCTION

### Facts about Mix Design

- Increase in filler results in lower AC
- Smaller Max agg size results in higher optimum AC content
- Manual hammer provides lower optimum AC content than mechanical
- Absorptive aggregate requires higher AC content
- Higher –200 results in higher marshall stability
- Reheating will significantly increase stability

#### MIX DESIGN CHECKLIST

- AGGREGATE QUALITY
- AGGREGATE GRADATION
- ASPHALT CEMENT GRADE
- ACCEPTABLE PEDESTAL
- SATISFACTORY HAMMER
- COMPACTION EFFORT
- COMPACTION TEMPERATURE
- VOLUMETRIC PROPERTIES
- STABILITY, FLOW, AND MOISTURE SUSCEPTIBILITY

### THE END

